



NO.	PARTS CODE	PARTS NAME	QT
1	FKE221	BOTTOM CASE ASSY	1
1c	FAA125-30	DUST SEAL	2
2	FEE239-01	BOTTOM STOPPER	1
3	FEE189-10	FORK NOSE	1
4	FKE123-00	SUPPORT TUBE ASSY	1
5	FKE091	PISTON ASSY	1
6	FKE222-20	UPPER ASSY	1
7	FAA196	O RING	2
8	FEE526	PISTON CAP	1
9	FKE072-10	AIR CAP ASSY	1
10	FAA150	VALVE CAP	1
11	FEE813-00	PRELOAD COVER	1
12	FUN006-15	DAMPER UNIT	1
13	FKE214-01	LO TOP CAP ASSY	1
14	FEE812-00	LO KNOB COVER	1
15	FEE809	ADJUST KNOB	1